



ROTOFRANCE

PORTAESCOBILLAS

PCB6807



12V Equivalente: 1 004 336 803, 804, 807, 819, 826, 840, 852, 909, 914, 924, 925, 931, 942, 947, 955, 956, 962, 976, 981, 984, 996, 997.

Aplicaciones: Audi: A6 / A8 / Quattro 4.2, Cabriolet 1.9, S6 / S8 4.2, BMW: M5 3.8 / Touring
Fiat: Duna 1.7D / Weekend Ford: Courier 1.8 Diesel, Escort 1.8, Express 55 / 75, Cabrio ,
Turnier Diesel Turbo, Mondeo 1.8 Turbo Jaguar: Xj6 4.0 M.Benz: Sprinter 312 D / 410 D
Peugeot: 306 1.9D / 405 1.9D Porsche: Boxter 2.5 I Renault: Safrane 2.2 I, Land Rover:
Defender, Discovery, Range Rover I / II, Volkswagen: Passat 2.5 Tdi Imp., Volvo: 850 2.5 Glt,
960 3.0

Arranques: 0 001 109 001-003, 006-009, 014, 017, 018, 021, 022, 025, 026,
028, 030, 031, 033, 036, 040, 043, 045, 048, 049, 057, 058, 0 001 110 004, 005, 007, 008,
011-013, 016, 017, 019, 022-025, 027-030, 039-046, 048, 049, 051-056, 063-068, 071, 072,
075, 078, 079, 082, 088-092, 100-102, 104-108, 110-113, 115, 120, 122-127, 999, 0 001 115
002, 007, 0 001 123 001, 0 001 124 015, 0 001 125 501-504, 507, 508, F 010 ALO 101.